



AXKID One³

AXKID One 3 is designed to make extended rear-facing travel as foolproof as possible. By following the 6-step guided process, the seat can be installed correctly and securely in under 30 seconds.

Scan the QR code for a video walk-through of the One 3 installation:



1

Rotate the load leg downward until you hear a 'click' and the indicator turns green.

2

While holding the handle at the back of the seat, slide the button on the anti-rebound bar, and fold the anti-rebound bar toward the car seat.

3

Connect the rigid LATCH connectors to the vehicle's lower anchors, and release the anti-rebound bar.

4

Turn the tensioning knob clockwise until you hear a 'click'.

5

Extend the load leg to the floor of the vehicle, ensuring the load leg contact indicator is green.

6

Install the AXKID Side Impact Protection (ASIP) pod on the side of the seat closest to the vehicle door.